



Important safety instructions	3
Disposal instructions	4
Your LCD TV overview	5
Front and side panels	5
Rear panel view	6
Remote control	7
General keys	7
Teletext and Multimedia	8
Basic connections	9
Connecting the power cord	9
Setting up the remote control	9
Enjoying analog and digital TV	9
Connecting an antenna/cable	9
Getting started watching your TV	10
Wall mount preparation / removing the base	11
Connecting external audio/video devices	12
Connecting a DVD, VCR, STB or audio/video equipment	12
Connecting a camera, camcorder or game console	13
Connecting a PC or notebook computer	14
Connecting a USB storage device	14
Selecting the input source	15
Playing multimedia files from a USB storage device	16
Connecting a USB storage device	16
Navigating in the multimedia screen	16
Channel controls	19
Channel list	19
Favourite channel list	20
Programme information	21
Electronic programme guide	21
OSD navigation	23
Navigating the OSD with the remote control	23
Adjusting the OSD settings	24
OSD menus	26
Picture settings	26
Sound settings	27
PAP function	28
Options settings	28
Timer settings	29
Lock settings	30
Setup the TV	31
Troubleshooting	33
PC Input Signal Reference Chart	34
Product specifications	35

Model Number: _____
Serial Number: _____
Purchase Date: _____
Place of Purchase: _____

	HDMI, the HDMI logo and High-Definition Multimedia Interface are trademarks or registered trademarks of HDMI Licensing LLC.
	DVB is a registered trademark of the DVB Project.

Important safety instructions

Read these instructions carefully. Please put them somewhere safe for future reference.

1. Only use attachments/accessories specified by the manufacturer.
2. Use only with the cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a cart is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over.
3. Unplug this apparatus during lightning storms or when unused for long periods of time.
4. Do not install this equipment in a confined space such a book case or similar unit.
5. No naked flame sources, such as lighted candles, should be placed on the apparatus.
6. If the remote control will not to be used for a long time, remove the batteries. Use the remote control carefully. Do not drop the remote control on the floor. Keep it away from moisture, direct sunlight, and high temperatures.
7. Used or discharged batteries must be properly disposed of or recycled in compliance with all applicable laws. For detailed information, contact your local solid waste disposal authority.
8. Follow all warnings and instructions marked on the product.
9. Unplug this product from the wall outlet before cleaning. Do not use liquid cleaners or aerosol cleaners. Use a damp cloth for cleaning.
10. Do not use this product near water.
11. Do not place this product on an unstable cart, stand or table. The product may fall, sustaining serious damage.
12. Slots and openings are provided for ventilation; to ensure reliable operation of the product and to protect it from overheating, these openings must not be blocked or covered. The openings should never be blocked by placing the product on a bed, sofa, rug or other similar surface. This product should never be placed near or over a radiator or heat register or in a built-in installation unless proper ventilation is provided.
13. This product should be operated from the type of power indicated on the marking label. If you are not sure of the type of power available, consult your dealer or local power company.
14. Do not allow anything to rest on the power cord. Do not locate this product where the cord will be stepped on.
15. If an extension cord is used with this product, make sure that the total ampere rating of the equipment plugged into the extension cord does not exceed the extension cord ampere rating. Also, make sure that the total rating of all products plugged into the wall outlet does not exceed the fuse rating.
16. Never push objects of any kind into this product through cabinet slots as they may touch dangerous voltage points or short-out parts, which could result in a fire or electric shock. Never spill liquid of any kind on the product.
17. Do not attempt to service this product yourself, as opening or removing covers may expose you to dangerous voltage points or other risks. Refer all servicing to qualified service personnel.
18. Unplug this product from the wall outlet and refer servicing to qualified service personnel under the following conditions:
 - a. When the power cord or plug is damaged or frayed.
 - b. If liquid has been spilled into the product.



- c. If the product has been exposed to rain or water.
 - d. If the product does not operate normally when the operating instructions are followed. Adjust only those controls that are covered by the operating instructions. Improper adjustment of other controls could result in damage; extensive work by a qualified technician might then be required to restore the product to normal condition.
 - e. If the product has been dropped or the case has been damaged.
 - f. If the product exhibits a distinct change in performance, indicating a need for service.
19. Use only the proper type of power supply cord set (provided in your accessories box) for this unit. Always disconnect the power cord from the wall outlet before servicing or disassembling this equipment.
 20. Do not overload an electrical AC outlet, power strip, or convenience receptical. The overall system load must not exceed 80% of the branch circuit rating. If power strips are used, the load should not exceed 80% of the power strip input rating.
 21. Some products are equipped with a three-wire electrical grounding-type plug that has a third pin for grounding. This plug only fits into a grounded electrical outlet. This is a safety feature. Make sure the AC outlet is properly grounded. Do not defeat the safety purpose of the grounding-type plug by trying to insert it into a non-grounded outlet. If you cannot insert the plug into the outlet, contact your electrician to replace the obsolete outlet.
 22. Do not use this LCD TV in the workplace in accordance with BildscharbV, and maintain ample distance from it when watching. Watching a big-screen TV too close can cause eyestrain.
 23. This TV is designed for home entertainment purposes only. Make sure there is sufficient distance between you and the TV when you are viewing content to avoid harming your eyes.



The grounding pin is an important safety feature. It is possible to receive an electric shock from a system that is not properly grounded.



The grounding pin is also providing good immunity ability against unexpected noise that interferes performance of this product and is produced by other nearby electrical devices.

Disposal instructions

Do not throw this electronic device into the rubbish bin / container when discarding. To minimize pollution and ensure utmost protection of the global environment, please recycle.

For more information regarding WEEE, please refer to <http://global.acer.com/about/environmental.htm>

Соответствует сертификатам, обязательным в РФ
(Compliant with Russian regulatory certification)





ME61

Your LCD TV overview

Front and side panels



1	Common interface
2	USB port
3	HDMI 3 port
4	Earphone



5	Power button	Turns the TV ON or OFF.
6	Menu key	Turns the OSD menu ON or OFF.
7	Volume up	When the OSD is on, functions the same as the Right arrow.
8	Volume down	When the OSD is on, functions the same as the Left arrow.
9	Channel up	When the OSD is on, functions the same as the Up arrow.
10	Channel down	When the OSD is on, functions the same as the Down arrow.


Rear panel view

1	AC-in	6	SPDIF out
2	HDMI 1 port	7	HDMI 2 port
3	AV 1 (SCART)	8	VGA-in + PC Audio L/R
4	COMPONENT-in + Audio-in L/R	9	Antenna/Cable-in
5	AV 2 in-CVBS + Audio L/R		



Remote control

General keys



1 POWER

Press to turn your TV on/off.

2 DISPLAY

Press to display or change input/channel information (dependent on input/source type).

3 GUIDE

Press to launch Electronic Programme Guide (EPG) mode (Digital TV mode only). See page 22.

4 SOURCE

Press to display the Source menu.

5 WIDE

Press to toggle scaling mode between Cinerama, 14:9 Zoom, 16:9 Zoom, 16:9

Zoom up, 16:9 format and 4:3 format modes.

6 MPX

Press to select a sound type available for the selected analogue TV programme; to select an audio language available for the selected digital TV programme.

7 MENU

Press to open the Menu.
Press to back to the previous menu.

8 BACK/CANCEL

Press to close the Menu.
Press to exit some operations.
Press to go back to the previously viewing channel.

9 DIRECTIONAL KEYS

In menu operation, press the up/down directional keys to select a certain option and press the left and right directional keys to adjust.

10 OK/ENTER/CH LIST

ENTER: Press to confirm a selection.
CH LIST: Press to launch the channel list. See page 19.

11 MUTE

Press to toggle audio on and off.

12 FAV

Press to display the favorite channel list.

13 VOL (+/-)

Press to increase or decrease the volume.

14 CH (up/down)

Press to sequentially select the TV channel and other source input.

15 NUMBER KEYS


16 TELETEXT

Press to switch from TV/AV to Teletext mode.
Press again to overlay teletext page on the TV image.

17 SUBTITLE

Press to select a subtitle language available for the selected digital TV programme.

Teletext and Multimedia



Teletext

- 1 Colour buttons (R/G/Y/B)**
Operates corresponding button on the teletext page.
- 2 INDEX**
No function.
- 3 SIZE**
Press once to zoom teletext page to 2X and view the top part.
Press twice to view the bottom part of 2X teletext page.
Press again to resume.
- 4 HOLD**
Press to pause the current teletext page.
- 5 REVEAL**
Press to reveal hidden teletext information.

Multimedia


- 1 Colour buttons (R/G/Y/B)**
Press to do special functions according to the hints on the bottom of the screen.
- 2 Previous Track**
Press to go to the beginning of a track, or the previous track.
- 3 Stop**
Press to stop playback.
- 4 Play/Pause**
Press to start playing the selected track, or pause a track if it is already playing.
- 5 Next track**
Press to skip to the next track if multiple tracks have been selected.
- 6** You may use the left and right directional buttons to advance or rewind in a track. Press the button again to increase how fast the track advances.
Press the Play/Pause button to resume playback.

The left and right directional keys also function as rewind and fast-forward keys when viewing multimedia files.

Basic connections

Connecting the power cord

- 1 Connect the AC cord into the AC input on the back of the set.
- 2 Connect the plug to the wall outlet as shown.




Setting up the remote control

- 1 Open the cover on the bottom of the remote unit.
- 2 Insert two AA batteries (supplied) to match the polarity indicated inside the battery compartment.


Enjoying analog and digital TV

Connecting an antenna/cable

Connect the antenna cable to the appropriate antenna terminal on the back of the TV set as shown below.



Getting started watching your TV



1 Power

Press the power button on the remote control or TV set.

2 Installation Guide

The first time you switch on the TV, you will be asked to select the language and scan for channels.

Press the **OK** key to begin the setup process.

Step 1. Select the setup language you prefer.



You can also adjust these settings using the side control panel. Please see "Front and side panels" on page 5 for details.

Step 2. Please select the correct country for signal reception.

Step 3. Select **the correct the tuner** mode.

Step 4. Ensure that your co-axial cables are connected correctly before proceeding.

Step 5. Scan for digital channels and analog channels.

Step 6. Select **Home** mode.

Step 7. Setup is now complete. You are ready to begin watching TV.

3 Changing channels

a. Press **0 - 9** on the remote control to select a channel. The channel changes after 2 seconds. Press **OK** to select the channel immediately.

b. Pressing the channel (**CH**) up / down button on the remote control will also change the channel.

4 Adjusting the volume

Adjust the volume level using the (**VOL**) up/down button on the remote control.



Setup may vary due to local broadcast differences.


Wall mount preparation / removing the base




Caution: Disassemble the base carefully otherwise the plastic parts and/or TV body may be damaged.

- 1) Remove the base.
- 2) Remove the screws from inside the stand.

AT2617MF



AT3217MF




- 3) Assemble the wall mount following the instructions included with the wall mount.

Connecting external audio/video devices

Connecting a DVD, VCR, STB or audio/video equipment


Connect your DVD player, VCR or audio/video equipment using the input ports located at the rear of your LCD TV as shown below.

Source-in




* Acer recommends the following priority for connection types:
HDMI -> COMPONENT -> AV 1 (SCART) -> AV 2 (Composite).

TV-out




Connecting a camera, camcorder or game console

Connect your camera or camcorder to the video/audio ports on the TV set as shown below.



Connecting a PC or notebook computer


To display PC output on your TV, connect your PC or notebook computer to the TV as shown below.



For VGA connections, Acer recommends setting your PC's external monitor resolution to 1920 x 1080 pixels @ 60 Hz refresh rate for AT3217MF and 1366 x 768 pixels @ 60 Hz refresh rate for AT2617MF.

Connecting a USB storage device


To display multimedia content on your TV, connect the USB device to the TV as shown below.



Selecting the input source

Once you have connected your antenna or external equipment to the TV, you need to select the correct input source.

Press the **SOURCE** button on the remote control to display the Source menu. Use the up/down **directional keys** to navigate the list and press **OK** to confirm the input you wish to watch: TV / AV1 / AV2 / CMP / VGA / HDMI 1 / HDMI 2 / HDMI 3.



Playing multimedia files from a USB storage device

Connecting a USB storage device

Connect the USB storage device to the USB port on your computer, the TV will enter the media center menu directly.

Supported file formats:

Picture JPEG

Music MP3


Video AVI, MPEG4, H.264, MPEG2, MPEG1...



Note: Some USB keys and USB products like digital cameras or mobile phones are not fully compatible with USB 2.0 standard so it may not work with the TV multimedia player.

Navigating in the multimedia screen

There are three main areas of the multimedia screen:



a. Status bar

The top of the screen shows some information about the selected file.

b. Navigation menu

The middle of the screen shows the contents of the USB device. Press the red/green button to page up/down. Use the directional keys and press **OK** to open a file or folder.



Note: Only files that match the selected media type are displayed.

Press the **BACK** button to return to the folder that contains the folder being viewed.

c. File option bar

The bottom of the screen shows additional options for the file being viewed, such as volume level or special functions for the coloured buttons on the remote control.



Note: When playing a movie or viewing photos, the top and bottom bars will disappear after a short delay. Press **OK** to display them.

View Picture

Select a picture and press **OK** to open it. Picture files will be shown in a slideshow. Press **OK** or **Play/Pause** to pause the display on a specific photo.




Press **Previous ('Index') / Next ('Reveal')** to return to the previous picture, or to view the next picture.

Press the red color key to display the options list and use up/down to select an option and left/right to adjust. During the slideshow, press **OK** to pause on a certain picture and you can use the yellow key to rotate the picture.

Press **BACK** to return to the folder navigation list

Listen Music

Select a music file and press **OK** to open it. Press **OK** or **Play/Pause** to pause a track.



Press **Previous ('Index') / Next ('Reveal')** to skip to the previous track or advance to the next track in the folder.


Press the red color key to display the options list and use up/down to select an option and left/right to adjust.

Press the left and right directional keys to advance or rewind (x2/x4) in a track.

Press **BACK** to return to the folder navigation list and preview screen.

Watch video

Select a movie file and press **OK** to open it. Press **OK** or **Play/Pause** to pause a movie.



Press **Previous ('Index')** / **Next ('Reveal')** to skip to the previous movie or advance to the next movie in the folder.

Press the red color key to display the options list and use up/down to select an option and left/right to adjust.

You may use the left and right directional keys to advance or rewind in a movie. Press the key again to increase how fast the track advances or rewinds (x2/x4/x8/x16/x32).

Press **BACK** to return to the folder navigation list and preview screen.

Leaving multimedia storage display

Repeatedly press **BACK** to exit the USB storage.







Warning: Do not remove the USB storage device while a media file is playing. Stop playback and switch to a different source before removing the device from the USB port.

Channel controls

Channel list

Channel list allows you to quickly find the TV channel you are searching for.



To open the channel list feature:		
1		Press the OK key on the remote control. This will bring up the channel list menu.
2		The current channel will be highlighted.
3		<p>Use the up/down directional keys to navigate the list and select the channel you wish to watch.</p> <p>Use the yellow key to switch to the channel list selection menu and press up/down to switch between the All, Digital, Radio and Analog channel lists.</p> <p>Use the blue key to exit the list.</p>

Favourite channel list

The favourite channel list allows you to store your favourite TV channels and flick between them at the touch of a button.

Viewing your favourite channels



On the remote control, if you press the **FAV** key, the TV will display a list of favourite TV channels. Use the up or down directional keys to select a channel, and then press **OK**.

To set a favourite channel, follow the steps described on this page.

Storing favourite channels

1



Press the **FAV** key on the remote control. This will bring up the favourite channel list.

2



The Favourite list will be shown. Press **OK** to select, delete or add a favourite channel.

3



Press the **BACK** key on the remote control to exit.

Guide screen

There are four main areas of the EPG screen:




The top of the screen shows the viewing date and the current time.

The section on the left shows all names for digital channels.

The section on the right shows information about programmes for the selected channel: the start and finish times, any age rating and a summary.

Use the up or down directional keys to switch to the previous or next channel.

Navigating the EPG (for Digital TV mode)






1		Press the GUIDE key on the remote control.
2		Use the directional keys to navigate around the EPG menu and press OK to select your highlighted option.

OSD navigation

Many of the advanced settings and adjustments are available through using the OSD (onscreen display) menus, as shown in the example screenshot below.

Basic operations required to navigate these menus (Picture, Sound, PAP, Options, USB, Timer, Lock and Setup) are described in this section.

Navigating the OSD with the remote control



You can also interact with these menus using the right panel controls. Please see "Front and side panels" on page 5 for details.

There are eight main OSD menus. These are: Picture, Sound, PAP, Options, USB, Timer, Lock and Setup. Use the following method to navigate these menus.


1		Press the MENU button on the remote control or the MENU button on the control panel.
2		Select your desired menu by using the up/down and left/right directional keys to switch between the eight menus. Press OK to enter a menu. Press MENU to return to the main menus.
3		Use the directional keys to interact with the menu. The up / down directions will scroll through the menu options, while left/right will adjust the different settings (for example, in the Picture menu, settings such as brightness, contrast, etc.). For some options with submenu, press OK or right to enter. Press BACK to exit.

Adjusting the OSD settings

The OSD can be used for adjusting the settings of your LCD TV.


Press the **MENU** key to open the OSD. You can use the OSD to adjust the picture quality, audio settings, channel settings and general settings. For advanced settings, please refer to the following page:

Adjusting picture quality




- 1 Press the **MENU** key to bring up the OSD.
- 2 Using the directional keys, select **Picture** from the OSD. Then navigate to the picture element you wish to adjust.
- 3 Use the left or right keys to adjust the sliding scales or select one of the preset picture modes. Press **MENU** to save and exit.
- 4 The **Picture** menu can be used to adjust the current **Picture preset**, **Brightness**, **Contrast**, **Saturation**, **Sharpness** and other image-related qualities.

Adjusting sound settings




- 1 Press the **MENU** key to bring up the OSD.
- 2 Using the directional keys, select **Sound** from the OSD. Then navigate to the feature you wish to adjust.
- 3 Use the left or right keys to adjust the sliding scales or select one of the preset sound modes. Press **MENU** to save and exit.
- 4 The **Sound** menu can also be used to adjust the current **Sound preset**, **Balance**, **Bass**, **Treble** and other important sound-related settings.

Adjusting PAP settings




- 1 Press the **MENU** key to bring up the OSD.
- 2 Using the directional keys, select **PAP** from the OSD.
- 3 Use the left/right directional keys to turn on PAP function.
- 4 When the PAP is turned on, you can adjust the **TV position**: Left or Right.

Adjusting options settings




- 1 Press the **MENU** key to bring up the OSD.
- 2 Using the directional keys, select **Options** from the OSD. Then navigate to the feature you wish to adjust.
- 3 The **Options** menu can be used to adjust the screen **Subtitle**, **Decoding page language**, **Digital teletext language** and other important settings.

Adjusting timer settings




- 1 Press the **MENU** key to bring up the OSD.
- 2 Using the directional keys, select **Timer** from the OSD. Then navigate to the feature you wish to adjust.
- 3 The **Timer** menu can be used to select the **Time zone**, **clock** and **Sleep timer**.

Adjusting lock settings



- 1 Press the **MENU** key to bring up the OSD.
- 2 Using the directional keys, select **Lock** from the OSD. Then navigate to the feature you wish to adjust.
- 3 The **Lock** menu can be used to adjust the **Channel lock**, **Parental rating**, **Input block**, **Front panel lock** and other important settings.

Adjusting Setup settings



- 1 Press the **MENU** key to bring up the OSD.
- 2 Using the directional keys, select **Setup** from the OSD. Then navigate to the feature you wish to adjust.
- 3 The **Setup** menu can be used to adjust the **Language**, **Country**, **Channel install**, **Organiser** and other important settings.



The options available on the OSD may vary depending on the TV signal source and model. Some digital options may not be available with an analog signal and vice versa.

OSD menus

Picture settings

Open the Picture menu as described in the **OSD navigation** section. This menu provides the following settings:

Picture preset

This TV provides preset viewing modes designed to give you the best picture quality when watching a particular kind of programme. These provide preset values for brightness, contrast, hue colour and sharpness. There are pre-defined audio and video settings for optimal enjoyment of the following viewing modes: Vivid, Standard, Movie, Studio, Personal.

Mode	Information
Vivid	Vivid mode allows you to watch your favourite channels with brilliant image via adaptive brightness and contrast adjustments for bright surroundings.
Standard	Standard mode allows you to watch your favourite channels with sharp, brilliant imagery via adaptive brightness and contrast adjustments for most living room conditions.
Movie	For comfortably enjoying movies at home, Movie mode displays dim scenes in clear detail; compensates for colour; and smoothly presents motion images. This is accomplished through optimal Gamma correction plus saturation, brightness and contrast adjustments.
Studio	Studio mode allows you to watch your favourite channels with sharp, brilliant imagery via adaptive brightness and contrast adjustments.
Personal	Personal mode allows you to save your favourite video settings.

Brightness

Change the brightness of the image.

Contrast

Change the contrast of the image.

Saturation

Change the colour depth of the image.

Sharpness

Change the sharpness of the image.

Color temperature

This setting adjusts the color temperature of the image. You can set it to Normal, Warm, Cool depending on your preference.

Screen mode

This setting adjusts the screen mode of the image. You can set it to Cinerama, 14:9 Zoom, 16:9 Zoom, 16:9 Zoom up, 16:9 format and 4:3 format modes depending on your preference.

Auto format

Turn on or off auto format function.

Noise reduction

Reduce any noise on the video signal.

ECO Dynamic back light

This setting adjusts the power saving mode. You can set it to Auto, High, Middle and Low depending on your preference.

Sound settings

Open the Sound menu as described in the **OSD navigation** section. This menu provides the following settings:

Sound preset

This TV provides preset audio modes designed to give you the best sound quality when listening to a particular kind of programme. These provide preset values for treble and bass. There are pre-defined audio and video settings for optimal enjoyment of the following scenarios: Speech, Music, Movie, Multimedia, Personal. For example, Music mode accentuates symphonic harmonies and the tenor audio range.

Balance

Change the balance between the left and right speakers.

Bass

Change the bass.

Treble

Change the treble.

Wide stereo

Turn wide stereo on to add virtual surround sound.

Auto volume control

This function prevents sudden changes in the audio output level. If this function is On, volume levels will be consistent when switching between input sources and changing channels.

Sound type

Select a sound type available for the selected analog programme.

Audio language

Select an audio language available for the selected digital programme.

PAP function

Open the PAP menu as described in the OSD navigation section. This menu provides the following settings:

PAP (Picture-And-Picture)

Turn the PAP function on or off. When PAP function is turned on, you can display the pictures from different source inputs side by side. Note that one window is for analogue or digital TV inputs, the other is for VGA, HDMI or CMP inputs.

Note: this PAP function is not available for AV inputs.

TV position

Select the position for TV input window, left or right.

You can toggle the focus window by pressing the left/right directional keys. When focus in TV input window, the digit keys and CH+/- keys work in TV input window. When focus in the other window, CH+/- keys can change available extension sources.

Options settings

Open the Options menu as described in the OSD navigation section. This menu provides the following settings:

Subtitle

Use these settings to adjust subtitles.

Subtitle

Turn on or off subtitles.

Digital subtitle language

Select a language as your preferred subtitle language.

Digital subtitle language 2nd

Select a language as your secondary subtitle language.

Subtitle type

You can choose between normal subtitles and subtitles for the hearing impaired, when these are available.

Decoding page language

Select the type of language used for teletext pages.

Decoding Teletext language

Select the primary language used for digital teletext pages.

SPDIF type

Select the sound type for the current programme for the audio device connected to the SPDIF output connector. The options depend on the programme you are watching. If the programme outputs sound in Dolby D format, you can select Dolby D or PCM. If the programme does not output sound in Dolby D format, you can select PCM only or no sound output. You can select Off to turn off the sound output.

SPDIF delay

If PCM is selected for SPDIF type, you can adjust the delay time to synchronize the sound with the image at this option.

Clear. fi Link

Turn on or off HDMI CEC function. When turned on, this enables one-touch play and one-touch standby for CEC devices connected to your TV's HDMI sockets.

Use one-touch play: one-touch play enables you to press the play button on, for example, your DVD remote control to start playback on your DVD devices and automatically switches your TV to the correct source displaying DVD content.

Use system standby: system standby enables you to press the power button on, for example, your TV remote control to switch your TV and all connected HDMI devices to standby mode.

Network update

Turn on or off network update function.

Common interface

Displays information about any card installed in the common interface slot.

Caution: Switch off the TV before inserting a card. Be sure to insert the card gently and push it in as far as it will go. Incorrect insertion may damage both the card and your TV.

Software update

Current version

Display the current version of the software.

By Channel

Allow to install the new version of the software if available.

Location

Select your location: Home or Shop.

Timer settings

Open the Timer menu as described in the OSD navigation section. This menu provides the following settings:

Time zone

Select a time zone.

Clock

Auto synchronization

If auto synchronization is on, the TV will set the time from digital channels

Time

If auto synchronization is turned off, you can set the time manually.

Power on timer

If this is on, the TV will power on at the set time.

Power off timer

If this is on, the TV will power off at the set time.

Sleep timer

Set a time for sleep timer or turn off sleep timer. The TV will power off when the countdown timer finishes.

Lock settings

Open the Lock menu as described in the OSD navigation section. Lock menu allows you to enter a password and effectively stop anyone without the password from watching TV. The default password is 0000. Super password is 0423. If you forget your code, use the super password to override any existing codes.

This menu provides the following settings:

Channel block

Press **OK** or right to see the list of channels. Use the up and down directional keys to select the channel to block and then press **OK** to lock. Press the **OK** again to unblock a channel.

When viewing channels, if a blocked channel is selected the TV will ask for your password. Enter your password to view the channel.

Parental rating

Most digital TV allows you to block content according to rating systems. The rating system used is dependent on region, and is only available on digital channels. Analog channels will not be blocked with this option.

Age rating (for digital TV)

The settings cover from 4 to 18 years of age and X-rated (Spain). When you lock a category, the categories for that age and younger will be blocked.

Input block

Press **OK** to see the list of input sources (AV, HDMI, etc.). Use the up and down directional keys to select the input source to block and then press **OK** to lock. Press the **OK** again to unblock an input source.

Front panel lock

Lock or unlock the keys on the side panel.

Lock installation

Lock or unlock the setup menu.

Max volume

Set a maximum volume.

Change password

You can change the default password to a 4-digit code of your choice. If you are using parental controls, then we recommend you change the password periodically.

Clean all

Return all parental settings to default values, removing any changes.

Setup the TV

Open the Setup menu as described in the OSD navigation section. This menu provides the following settings:

Language

Use these settings to adjust language.

Menu language

Select your desired language to display the menus.

Preferred audio language

Select a language as your preferred audio language.

Preferred audio language 2nd

Select a language as your secondary audio language.

Tuner mode

Select a tuner mode: Antenna or Cable.

Country

Select the country you live in to scan for the correct signals.

Channel install

Automatic search

Automatic search allows you to scan for channels. If you completed the setup wizard the first time you turned on your TV, all available channels are listed.

Wait until the scan has finished; this will take several minutes. During the scanning process, press **MENU** or **BACK** to abort halfway with all searched channels saved.

Automatic update

If the tuner mode is Antenna, you can use Automatic update to scan for new or deleted channels.

Analog manual installation

You can manually add an analog channel by adjusting the settings here.

Digital manual installation

You can manually add a digital channel by searching in specific UHF channels.

Organiser

You can use these settings to skip channels, change a channels' number and name or sort channels.

Channel skip

Use the up/down directional keys to select a channel and press **OK** to check/uncheck the box. If checked, the channel is skipped. The skipped channel can not be accessed by pressing the **CH+/-** keys but can be accessed by entering the channel number.

Channel sort

You can exchange two channels. Use the up/down directional keys to select a channel and press **OK** to select with a tick icon. Then use the up/down directional keys to select another channel and press **OK** to exchange.

Channel edit

Use the up/down directional keys to select a channel and press **OK** to enter the editing menu. Use the left/right directional keys to move the cursor and the number keys to enter channel number or channel name and press **OK** to save and back to the previous menu.

Input settings

Select a type of apparatus for each connector with equipment connected.

Decode

Use the up/down directional keys to select an analog channel and press **OK** to decode.

Diagnostics

Display some signal information on current digital channel.

Reset shop

Allow you to reset the TV to factory default settings. You have to enter a correct password to reset all settings. After resetting the initial setup menu will appear.

Troubleshooting

Before you call the Acer service center, please check the following items:

Here is a list of possible situations that may arise during the use of your LCD TV. Easy answers and solutions are provided for each.

There is no picture or sound

- Make sure the power cord is properly inserted in the power outlet.
- Make sure the input mode is correctly set by your selected input.
- Make sure the antenna at the rear of the TV is properly connected.
- Make sure the main power switch is turned on.
- Make sure the volume is not set to minimum or the sound is not set to mute.
- Make sure the headphones are not connected.
- Reception other than those of broadcasting stations can be considered.

Picture is not clear

- Make sure the antenna cable is properly connected.
- Consider whether your TV signal is being properly received.
- Poor picture quality can occur due to a VHS camera, camcorder, or other peripheral being connected at the same time. Switch off one of the other peripherals.
- The 'ghost' or double image may be caused by obstruction to the antenna due to high-rise buildings or hills. Using a highly directional antenna may improve the picture quality.
- The horizontal dotted lines shown on the pictures may be caused by electrical interference, e.g., hair dryer, nearby neon lights, etc. Turn off or remove these.

Picture is too dark, too light or tinted

- Check the colour adjustment.
- Check the brightness setting.
- Check the sharpness function.
- The fluorescent lamp may have reached the end of its service life.

Remote control does not work

- Check the batteries of the remote control.
- Make sure the remote sensor window is not under strong fluorescent lighting.
- Try to clean the remote control sensor lens on the TV with a soft cloth.
- Use the buttons (hotkeys) on the TV before the remote control works.

If the above suggestions do not solve your technical issue, please refer to the warranty card for service information.

PC Input Signal Reference Chart

AT2617MF

Item	Resolution	Frequency (Hz)
1	640x480	60
2	640x480	75
3	800x600	60
4	800X600	75
5	1024x768	60
6	1024x768	75
7	1360x768	60

AT3217MF

Item	Resolution	Frequency (Hz)
1	640x480	60
2	640x480	75
3	800x600	60
4	800x600	75
5	1024x768	60
6	1024x768	75
7	1280x1024	60
8	1280x1024	75
9	1600x1200	60
10	1360x768	60
11	1920x1080	60



PC input does not support Sync on Green, Composite Sync or interlaced signals.

Product specifications

Model	AT2617MF	AT3217MF
Panel spec		
Resolution (pixels)	1366 x 768	1920 x 1080
Brightness (typ.)	350 cd/m ²	400 cd/m ²
Dynamic Contrast Ratio (max.)	5000:1	
Viewing angle (typ.)	89° (H), 89° (V)	
Response (typ.)	8 ms	6.5 ms
Power supply		
Input	220VAC~240VAC, 50 Hz	
Max. power consumption	80 W	110 W
Power saving	< 1 W	
Mechanical		
Dimensions (W x H x D mm)	663 x 494.5 x 202	796 x 565 x 281
Weight (kg)	7.4	12.2
Weight (lbs.)	15.17	25.01
Gross weight (Kg)	10.2	13.2
Gross weight (lbs)	20.91	27.06
Wall-mounting holes	VESA, 100 mm x 100 mm	VESA, 200 mm x 100 mm
Analog TV system		
Colour system	PAL, SECAM	
Sound system	B / G / D / K / I / L	
Stereo system	NICAM / A2	
Subtitle	Teletext 1.5 (1000 pages)	
Digital TV system		
Digital TV standard	DVB-T HD (H.264) / DVB-C	
Sound system	PCM/ MPEG (Layer I & II), HE-AAC Dolby Digital / Dolby Digital plus	
Frequency	7/8 MHz	

Model	AT2617MF	AT3217MF
Terminal		
Analog/Digital Tuner In	Hybrid	
SCART	CVBS (In), RGB (In), Audio R/L (In/Out), ATV/DTV CVBS out	
Component in	YPbPr, Audio (R/L)	
AV-in	CVBS, Audio (R/L)	
HDMI 1	Yes (HDMI 1.3)	
HDMI 2	Yes (HDMI 1.3)	
HDMI 3	Yes (HDMI 1.3)	
PC D-sub in	Yes	
PC audio in	Yes	
SPDIF out	Yes (Coxial)	
Headphone out	Yes	
USB Port	Yes	
HDMI	480i/p, 576i/p, 720p, 1080i, 1080p	
Speakers	3W x 2	5W x 2
Photo	JPG	
Audio	MP3	
Video	AVI, MPEG-4, H.264, MPEG-2, MPEG1	