


# Elenberg TV-707



17	SCREW KA2X6	10
16	SCREW PA2X6	7
15	POWER KEY	1
14	POWER KEY PCB	1
13	FRONT CABINET	1
12	REMOTE LENS	1
11	REMOTE PCB	1
10	7" LCD	1
9	MAIN PCB	1
8	BACK CABINET	1
7	BACK IRON	1
6	ANTENNA	1
5	SPEAKER	1
4	VOL+/-	1
3	CH+/-	1
2	KEY PCB	1
1	ALUMINIUM PLATE	1
NO.	DESCRIPTION	UNIT

ITEM	SIGN	DATE	NAME	ITEM
DRAWER			TV-707	SCALE
CHECKER				UNIT
ASSESSOR			MAT.	⊕ ⊖ A4

